

Party and exhibition tents system multiflex

Bolts =

6x70 Blue = Beam

6x90 Orange = Beam + 1

6x100 Pink = Beam + 2

Assembly guide

Skippy Bolts

10x160 = Red (Base Plate)

10x120 = Yellow (Gable Base Plate)


10x80 = Green (Gable Post)

10x130 = Purple (Brace Struts)

Type 6 to 15/250 P7

Losberger Intertent GmbH x Gottlieb-Daimler-Ring 14 x 74906 Bad Rappenau

Telefon (07066) 980-0 x Telefax 980-232



multiflex 12/... P7 Assembly guide, frame



